



# SAND & WATER TABLE










ITEM NO. 1351

**WARNING:**  
CHOKING HAZARD—Small parts.  
Not for children under 3 years.

# ASSEMBLY INSTRUCTIONS

Adult Assembly Required

## Contents





# SAND & WATER TABLE




ITEM NO. 1351

**WARNING:**  
CHOKING HAZARD—Small parts.  
Not for children under 3 years.

# ASSEMBLY INSTRUCTIONS

Adult Assembly Required

## Packing Away



### Help

If you are experiencing problems with this product, please visit our website [www.mookie.co.uk](http://www.mookie.co.uk) for assistance, advice and spare parts. You can also contact our helpline on 01525 722716 9am - 5pm weekdays.

## Interchangeable accessories



Option 1



Option 2



Option 3



Option 4

**WARNING!** Not suitable for children under 36 months. Choking hazard. Adult supervision recommended. For outdoors use only.

This product will last longer if not exposed to direct sunlight for long periods of time. Empty water from base to avoid it going stagnant. Store in a dry, frost free environment when not in use.